

# O Clam-P XL- APS-B Installation Manual

## Step 1:

Slide O Clam-P into mounting bracket.

Bolts should sit inside the mounting slots.



## Step 2:

Place O Clam-P and microinverter onto panel frame. It is recommended to stay within 7 inches from the corners or from a mounting clamp.

(Bolt heads of O Clam-P should face the rear of panel.)



## Step 3:

Tighten to 10 lb.-ft.

Use stainless steel cable clips for cable management.

\*\*For removal, undo bolts and remove microinverter.

\*\*\*Bonding screws will be embedded into the panel frame.

